CASIO 465 SOUND

◎トーンバンク音色の選び方

◆“FLUTE PIANO”を選ぶ場合
①トーンセレクターでPIANOを選びます。
②トーンバンクキーを押します（インジケーター点灯）
③トーンセレクターでFLUTEを選びます。



◆続いて“BELLS PIANO”を選ぶ場合
④操作③のあとで、そのままBELLSを選びます。

◆次に“HARPSI BRASS”を選ぶ場合
⑤トーンバンクキーを押します（インジケーター消灯）
⑥トーンセレクターでHARPSICHORDを選びます。
⑦もう1度，トーンバンクキーを押します（インジケーター点灯）
⑧トーンセレクターでBRASS ENSを選びます。

◎Selecting Tone Bank Sound Combin

◆To select “FLUTE PIANO” sound:
① Select PIANO tone with the tone sel
② Press the Tone Bank button. The ind button lights.
③ Select the FLUTE tone with the ton

◆Subsequently selecting “BELLS PIANO”
④ Press the BELLS tone selector.

◆To select “HARPSI BRASS” sound:
⑤ Press the Tone Bank button to turn indicator goes out.
⑥ Select the HARPSICHORD tone.
⑦ Press the Tone Bank button again. T
⑧ Select the BRASS ENS tone with th

	PIANO	HARPSICHORD	VIBRAPHONE	JAZZ ORGAN	PIPE ORGAN	BRASS ENS	STRING
PIANO		PF HARPSICHORD	VIBRAPHONE 2	PF J ORGAN	PF ORGAN 1	POPS ENS	ST PIAN
HARPSICHORD	PF HARPSICHORD		HARPSI VIB	HARPSI J ORGAN	HARPSI ORGAN 1	HARPSI BRASS	ST HAR
VIBRAPHONE	VIBRAPHONE 2	HARPSI VIB		VIB J ORGAN	VIB ORGAN 1	VIB BRASS	STRING
JAZZ ORGAN	PF J ORGAN	HARPSI J ORGAN	VIB J ORGAN		ELEC ORGAN 1	BRASS ORGAN	ST ORG
PIPE ORGAN	PF ORGAN 1	HARPSI ORGAN 1	VIB ORGAN 1	ELEC ORGAN 1		BRASS PIPE	STRING
BRASS ENS	POPS ENS	HARPSI BRASS	VIB BRASS	BRASS ORGAN	BRASS PIPE		STRING
STRINGS 1	ST PIANO 1	ST HARPSI 1	STRING VIB 1	ST ORGAN 1	STRING PIPE 1	STRING BRASS 1	
FLUTE	FLUTE PIANO	HARPSI FLUTE	VIB FLUTE	FLUTE ORGAN	PIPE ORGAN 2	BRASS FLUTE	FLUTE
CHORUS	PF CHORUS	HARPSI CHORUS	CHORUS VIB	CHORUS ORGAN	CATHEDRAL 1	SYNTH-BRASS 1	STRING
JAZZ GUITAR	PF GUITAR	GUITAR HARPSI	JAZZ VIB	ATTACK ORGAN	PIPE ORGAN 3	JAZZ BRASS 1	JAZZ S
BELLS	BELLS PIANO	HARPSI BELLS	BELLS VIB	BELLS ORGAN	CATHEDRAL 2	BRASS BELLS	BELLS
FUNKY CLAVI	PF CLAVI 1	HARPSI CLAVI 1	VIB CLAVI 1	ORGAN CLAVI 1	ROCK ORGAN 1	SYNTH-BRASS 2	ST CLA
METALLIC SOUND	METALLIC PIANO	METALLIC HARPSI	METALLIC VIB	METALLIC ORGAN	METALLIC PIPE	SYNTH-ENS 2	DIGITAL
SYNTH-ENS	SYNTH-PIANO	SYNTH-HARPSI	SYNTH-VIB	SYNTH-ORGAN	SYNTH-PIPE	SYNTH-ENS 3	SYNTH-
PERCUSSION	PERC PIANO	PERC HARPSI	PERC VIB	PERC J ORGAN	PERC PIPE	PERC BRASS	PERC S
HONKY-TONK PIANO	HONKY-TONK	HARPSICHORD 2	VIB PIANO	ORGAN ENS	CATHEDRAL 3	PIANO ENS	PF STR
ELEC PIANO	ELEC PIANO 2	ELEC HARPSI	ELEC VIB	ELEC ORGAN 2	ELEC ORGAN 3	PF BRASS	SYNTH-
MARIMBA	TOY PIANO	H MARIMBA	VIB MARIMBA	JAZZ ORGAN 2	MARIMBA ORGAN	JAZZ BRASS 2	SYNTH-
ORGAN	PF ORGAN 2	HARPSI ORGAN	VIB ORGAN 2	JAZZ ORGAN 3	PIPE ORGAN 4	ORG BRASS	ST ORG
ACCORDION	PF ACCORDION	H ACCORDION	VIB ACCORDION	JAZZ ACCORDION	PIPE ACCORDION	SYNTH-ACCORDION	ACCOR
TRUMPET	PF TRUMPET	HARPSI TRUMPET	VIB TRUMPET	TRUMPET ORGAN	TP PIPE ORGAN	SYNTH-BRASS 3	STRING
STRINGS 2	ST PIANO 2	ST HARPSI 2	STRING VIB 2	ST ORGAN 2	STRING PIPE 2	STRING BRASS 2	STRING
OBOE	OBOE PIANO	HARPSI OBOE	OBOE VIB	OBOE ORGAN	PIPE ORGAN 5	BRASS OBOE	STRING
SYNTH-REED	PF REED	HARPSI REED	VIB REED	ORGAN REED	PIPE REED	BRASS REED	ST REE
HARP	PF HARP	HARPSI HARP	HARP VIB	JAZZ ORGAN 4	PIPE HARP	BRASS HARP	HARP S
SYNTH-CELESTA	PF CELESTA	H CELESTA	VIB CELESTA	CELESTA ORGAN	PIPE CELESTA	SYNTH-SOUND 1	SYNTH-
SYNTH-CLAVI	PF CLAVI 2	HARPSI CLAVI 2	VIB CLAVI 2	ORGAN CLAVI 2	ROCK ORGAN 2	SYNTH-BRASS 4	ST CLA
FANTASY	FANTASY PIANO	FANTASY HARPSI	FANTASY VIB	FANTASY ORGAN	FANTASY PIPE	FANTASY BRASS	FANTAS
MIRACLE	MIRACLE PIANO	MIRACLE HARPSI	MIRACLE VIB	MIRACLE ORGAN	MIRACLE PIPE	MIRACLE BRASS	MIRACL
BASS	BASS PIANO	HARPSI BASS	BASS VIB	BASS ORGAN	BASS PIPE	BASS BRASS	BASS S

TONE BANK

ations

ector
icator above the

e selector

= FLUTE PIANO
FLUTE

sound:

= BELLS PIANO
BELLS

off this feature. The

he indicator lights.
e tone selector

= HARPSI BRASS
ASS ENS

◎Selección de las combinaciones del banco de sonido

◆Para seleccionar el sonido "FLUTE PIANO":

① Seleccione el sonido PIANO con el selector de sonido.
② Presione el botón de banco de sonido. Se ilumina el indicador sobre el botón.
③ Seleccione el sonido FLUTE con el selector de sonido.



◆A continuación seleccione el sonido "BELLS PIANO":

④ Presione el selector de sonido BELLS.



◆Para seleccionar el sonido "HARPSI BRASS":

⑤ Presione el botón de banco de sonido para desactivar esta característica. El indicador se apaga.
⑥ Seleccione el sonido HARPSICHORD.
⑦ Presione nuevamente el botón de banco de sonido. El indicador se ilumina.
⑧ Seleccione el sonido BRASS ENS con el selector de sonido.

◎Wahl von Tonbank-Sou

◆Wählen des "FLUTE PIAN

① Den PIANO Sound mi
② Die Tonbanktaste drü leuchtet.
③ Den FLUTE Sound mi

◆Danach den "BELLS PIAN

④ Den BELLS Klangfar

◆Wählen des "HARPSI BRA

⑤ Die Tonbanktaste drü schalten. Die Anzeige erl
⑥ Die HARPSICHORD
⑦ Die Tonbanktaste noc
⑧ Den BRASS ENS Sou wählen.

S 1	FLUTE	CHORUS	JAZZ GUITAR	BELLS	FUNKY CLAVI	METALLIC SOUND	SYNTH-ENS	PERCUSSION
IO 1	FLUTE PIANO	PF CHORUS	PF GUITAR	BELLS PIANO	PF CLAVI 1	METALLIC PIANO	SYNTH-PIANO	PERC PIANO
PSI 1	HARPSI FLUTE	HARPSI CHORUS	GUITAR HARPSI	HARPSI BELLS	HARPSI CLAVI 1	METALLIC HARPSI	SYNTH-HARPSI	PERC HARPSI
VIB 1	VIB FLUTE	CHORUS VIB	JAZZ VIB	BELLS VIB	VIB CLAVI 1	METALLIC VIB	SYNTH-VIB	PERC VIB
AN 1	FLUTE ORGAN	CHORUS ORGAN	ATTACK ORGAN	BELLS ORGAN	ORGAN CLAVI 1	METALLIC ORGAN	SYNTH-ORGAN	PERC J ORGAN
PIPE 1	PIPE ORGAN 2	CATHEDRAL 1	PIPE ORGAN 3	CATHEDRAL 2	ROCK ORGAN 1	METALLIC PIPE	SYNTH-PIPE	PERC PIPE
BRASS 1	BRASS FLUTE	SYNTH-BRASS 1	JAZZ BRASS 1	BRASS BELLS	SYNTH-BRASS 2	SYNTH-ENS 2	SYNTH-ENS 3	PERC BRASS
	FLUTE STRINGS 1	STRING CHORUS	JAZZ STRINGS	BELLS STRINGS	ST CLAVI 1	DIGITAL STRINGS	SYNTH-STRINGS 1	PERC STRINGS 1
STRINGS 1		FLUTE CHORUS	JAZZ FLUTE	BELLS FLUTE	FLUTE CLAVI 1	METALLIC FLUTE	SYNTH-FLUTE 1	PERC FLUTE
CHORUS	FLUTE CHORUS		ATTACK CHORUS	BELLS CHORUS	SYNTH-SOUND 3	METALLIC CHORUS	SYNTH-CHORUS 1	PERC CHORUS
TRINGS	JAZZ FLUTE	ATTACK CHORUS		BELLS GUITAR	FUNKY CLAVI 2	METALLIC GUITAR	SYNTH-GUITAR	PERC GUITAR
STRINGS	BELLS FLUTE	BELLS CHORUS	BELLS GUITAR		BELLS CLAVI 1	SYNTH-BELLS 1	BELLS ENS 1	PERC BELLS
VI 1	FLUTE CLAVI 1	SYNTH-SOUND 3	FUNKY CLAVI 2	BELLS CLAVI 1		METALLIC CLAVI	CLAVI ENS 1	PERC CLAVI
STRINGS	METALLIC FLUTE	METALLIC CHORUS	METALLIC GUITAR	SYNTH-BELLS 1	METALLIC CLAVI		DIGITAL ENS 1	METALLIC PERC
STRINGS 1	SYNTH-FLUTE 1	SYNTH-CHORUS 1	SYNTH-GUITAR	BELLS ENS 1	CLAVI ENS 1	DIGITAL ENS 1		SYNTH-PERC
TRINGS 1	PERC FLUTE	PERC CHORUS	PERC GUITAR	PERC BELLS	PERC CLAVI 1	METALLIC PERC	SYNTH-PERC	
NGS 1	STREET PIANO	CHORUS ENS 1	HT GUITAR	HT BELLS	HT CLAVI	SCRATCH PIANO	SYNTH-ENS 4	HT PERCUSSION
STRINGS 2	ELEC FLUTE	CHORUS ENS 2	ELEC PIANO 3	ELEC BELLS	ELEC CLAVI	ELEC PIANO 4	ELEC PIANO 5	ELEC PERC
STRINGS 3	JAZZ ORGAN 5	SYNTH-CHORUS 2	JG MARIMBA	BELLS MARIMBA	ATTACK CLAVI	DIGITAL MARIMBA	SYNTH-MARIMBA	PERC MARIMBA
AN 3	ORGAN 2	CHORUS ENS 3	JG ORGAN	CATHEDRAL 4	ORGAN CLAVI 3	DIGITAL ORGAN	ORGAN 3	PERC ORGAN
DION ENS	FL ACCORDION	CHORUS ENS 4	ACCORDION 2	BELLS ACCORDION	FUNKY ACCORDION	M ACCORDION	ACCORDION 3	PERC ACCORDION
BRASS 3	TRUMPET 2	SYNTH-CHORUS 3	JG TRUMPET	BELLS TRUMPET	FUNKY TRUMPET	DIGITAL SOUND	SYNTH-TRUMPET	PERC TRUMPET
S 3	FLUTE STRINGS 2	CHORUS ENS 5	GUITAR STRINGS	BELLS ENS 2	ST CLAVI 3	SYNTH-STRINGS 2	STRINGS 4	PERC STRINGS 2
OBOE	OBOE 2	OBOE CHORUS	JAZZ OBOE	OBOE BELLS	OBOE 3	METALLIC OBOE	SYNTH-OBOE	PERC OBOE
D	FL REED	SYNTH-CHORUS 4	JG REED	BELLS REED	FUNKY REED	DIGITAL REED	SYNTH-REED 2	PERC REED
TRINGS	HARP FLUTE	HARP CHORUS	HARP GUITAR	HARP BELLS	HARP CLAVI	METALLIC HARP	SYNTH-HARP	PERC HARP
SOUND 2	SYNTH-FLUTE 2	SYNTH-CHORUS 5	SYNTH-CELESTA 2	SYNTH-BELLS 2	FUNKY CELESTA	HARPSICHORD 3	SYNTH-CELESTA 3	PERC CELESTA
VI 2	FLUTE CLAVI 2	SYNTH-SOUND 4	SYNTH-CLAVI 2	BELLS CLAVI 2	CLAVI ENS 2	DIGITAL ENS 2	SYNTH-CLAVI 3	PERC CLAVI 2
Y STRINGS	FANTASY FLUTE	FANTASY CHORUS	FANTASY GUITAR	FANTASY BELLS	FANTASY CLAVI	FANTASY 2	FANTASY 3	PERC FANTASY
E STRINGS	MIRACLE FLUTE	MIRACLE CHORUS	MIRACLE GUITAR	MIRACLE BELLS	MIRACLE CLAVI	MIRACLE 2	MIRACLE 3	PERC MIRACLE
TRINGS	BASS FLUTE	BASS CHORUS	BASS GUITAR	BASS BELLS	SYNTH-BASS 1	METALLIC BASS	SYNTH-BASS 2	PERC BASS

nd-Kombinationen

NO" Sounds:

t dem Klangfarbenwähler wählen.

ken. Die Anzeige über der Taste

t dem Klangfarbenwähler wählen.

IO" Sound wählen:

penwähler drücken.



ASS" Sound:

cken, um diese Funktion auszu-

ischt.

Klangfarbe wählen.

mals drücken. Die Anzeige leuchtet.

nd mit dem Klangfarbenwähler



◎ Sélection des combinaisons sonores de banque de tonalités

◆Pour sélectionner le son "FLUTE PIANO":

① Sélectionner la tonalité de PIANO avec le sélecteur de tonalité.

② Appuyer sur la touche de banque de tonalités. Le témoin situé au-dessous de la touche s'allume.

③ Sélectionner la tonalité de FLUTE avec le sélecteur de tonalité.

◆Sélection par la suite du son "BELLS SOUND":

④ Appuyer sur le sélecteur de tonalité "BELLS"

◆Pour sélectionner le son "HARPSI BRASS":

⑤ Appuyer sur la touche de banque de tonalités pour désactiver cette caractéristique. Le témoin s'éteint.

⑥ Sélectionner la tonalité HARPSICHORD.

⑦ Appuyer à nouveau sur la touche de banque de tonalités. Le témoin s'allume.

⑧ Sélectionner la tonalité "BRASS ENS" avec le sélecteur de tonalité.

◎ Kiezen van

◆Voor keuze v

① Stel de

② Druk op

gaat brand

③ Stel de

◆Om daarna d

④ Druk op

◆Om de "HAR

⑤ Druk op

schakelen.

⑥ Stel de

⑦ Druk no

branden.

⑧ Stel de

	HONKY-TONK PIANO	ELEC PIANO	MARIMBA	ORGAN	ACCORDION	TRUMPET	STRINGS 2	OBOE	SY
	HONKY-TONK	ELEC PIANO 2	TOY PIANO	PF ORGAN 2	PF ACCORDION	PF TRUMPET	ST PIANO 2	OBOE PIANO	PF
	HARPSICHORD 2	ELEC HARPSI	H MARIMBA	HARPSI ORGAN	H ACCORDION	HARPSI TRUMPET	ST HARPSI 2	HARPSI OBOE	HA
	VIB PIANO	ELEC VIB	VIB MARIMBA	VIB ORGAN 2	VIB ACCORDION	VIB TRUMPET	STRING VIB 2	OBOE VIB	VI
	ORGAN ENS	ELEC ORGAN 2	JAZZ ORGAN 2	JAZZ ORGAN 3	JAZZ ACCORDION	TRUMPET ORGAN	ST ORGAN 2	OBOE ORGAN	OR
	CATHEDRAL 3	ELEC ORGAN 3	MARIMBA ORGAN	PIPE ORGAN 4	PIPE ACCORDION	TP PIPE ORGAN	STRING PIPE 2	PIPE ORGAN 5	PI
	PIANO ENS	PF BRASS	JAZZ BRASS 2	ORG BRASS	SYNTH-ACCORDION	SYNTH-BRASS 3	STRING BRASS 2	BRASS OBOE	BR
	PF STRINGS 1	SYNTH-STRINGS 2	SYNTH-STRINGS 3	ST ORGAN 3	ACCORDION ENS	STRING BRASS 3	STRINGS 3	STRING OBOE	ST
	STREET PIANO	ELEC FLUTE	JAZZ ORGAN 5	ORGAN 2	FL ACCORDION	TRUMPET 2	FLUTE STRINGS 2	OBOE 2	FL
	CHORUS ENS 1	CHORUS ENS 2	SYNTH-CHORUS 2	CHORUS ENS 3	CHORUS ENS 4	SYNTH-CHORUS 3	CHORUS ENS 5	OBOE CHORUS	SY
	HT GUITAR	ELEC PIANO 3	JG MARIMBA	JG ORGAN	ACCORDION 2	JG TRUMPET	GUITAR STRINGS	JAZZ OBOE	JG
	HT BELLS	ELEC BELLS	BELLS MARIMBA	CATHEDRAL 4	BELLS ACCORDION	BELLS TRUMPET	BELLS ENS 2	OBOE BELLS	BE
	HT CLAVI	ELEC CLAVI	ATTACK CLAVI	ORGAN CLAVI 3	FUNKY ACCORDION	FUNKY TRUMPET	ST CLAVI 3	OBOE 3	FU
	SCRATCH PIANO	ELEC PIANO 4	DIGITAL MARIMBA	DIGITAL ORGAN	M ACCORDION	DIGITAL SOUND	SYNTH-STRINGS 2	METALLIC OBOE	DI
	SYNTH-ENS 4	ELEC PIANO 5	SYNTH-MARIMBA	ORGAN 3	ACCORDION 3	SYNTH-TRUMPET	STRINGS 4	SYNTH-OBOE	SY
	HT PERCUSSION	ELEC PERC	PERC MARIMBA	PERC ORGAN	PERC ACCORDION	PERC TRUMPET	PERC STRINGS 2	PERC OBOE	PE
		ENKA SOUND 1	HT MARIMBA	HT ORGAN	ACCORDION 4	HT TRUMPET	PF STRINGS 2	HT OBOE	HT
	ENKA SOUND 1		ELEC MARIMBA	ELEC ORGAN 4	ELEC ACCORDION	ELEC TRUMPET	ELEC STRINGS	ELEC OBOE	SY
	HT MARIMBA	ELEC MARIMBA		ORGAN 4	A MARIMBA	M TRUMPET	ST MARIMBA	ENKA SOUND 2	MA
	HT ORGAN	ELEC ORGAN 4	ORGAN 4		ACCORDION 5	TRUMPET 3	SYNTH-STRINGS 3	OBOE 4	SY
N	ACCORDION 4	ELEC ACCORDION	A MARIMBA	ACCORDION 5		ACCORDION 6	SYNTH-STRINGS 4	OBOE ACCORDION	SO
	HT TRUMPET	ELEC TRUMPET	M TRUMPET	TRUMPET 3	ACCORDION 6		TRUMPET ENS	OBOE TRUMPET	SO
	PF STRINGS 2	ELEC STRINGS	ST MARIMBA	SYNTH-STRINGS 3	SYNTH-STRINGS 4	TRUMPET ENS		OBOE ENS	SO
	HT OBOE	ELEC OBOE	ENKA SOUND 2	OBOE 4	OBOE ACCORDION	OBOE TRUMPET	OBOE ENS		OB
	HT REED	SYNTH-REED 3	MARIMBA REED	SYNTH-REED 4	SOLO REED 1	SOLO REED 2	SOLO REED 3	OBOE REED	
	HARP PIANO	ELEC PIANO 6	HARP MARIMBA	ORGAN 5	POPS ACCORDION	HARP TRUMPET	SYNTH-STRINGS 5	HARP OBOE	HA
	SYNTH-CELESTA 4	ELEC CELESTA	SYNTH-CELESTA 5	ORG CELESTA	C ACCORDION	T CELESTA	SYNTH-ENS 5	OBOE CELESTA	SO
	SYNTH-CLAVI 4	ELEC CLAVI	SYNTH-CLAVI 5	ORGAN CLAVI 4	SYNTH-SOUND 5	TRUMPET CLAVI	ST CLAVI 4	OBOE 5	CL
	FANTASY 4	FANTASY 5	FANTASY MARIMBA	FANTASY 6	A FANTASY	FANTASY TRUMPET	DIGITAL ENS 3	FANTASY OBOE	FA
	MIRACLE 4	MIRACLE 5	MIRACLE MARIMBA	MIRACLE 6	A MIRACLE	MIRACLE TRUMPET	DIGITAL ENS 4	MIRACLE OBOE	MI
	BASS HT PIANO	BASS EL PIANO	BASS MARIMBA	ORG BASS	BASS ACCORDION	SYNTH-BASS 3	SYNTH-BASS 4	BASS OBOE	BA

toonbankklankkombinaties

an de "FLUTE PIANO" klank:
PIANO klank in met de toonkeuzeschakelaar
de toonbanktoets. De indikator boven de toets
en.
FLUTE toon in met de toonkeuzeschakelaar



e "BELLS PIANO" klank in te stellen:
de BELLS toonkeuzeschakelaar

PSI BRASS" klank in te stellen:
de toonbanktoets om deze funktie uit te
De indikator gaat uit.
HARPSICHORD toon in.
gmaals op de toonbanktoets. De indikator gaat

BRASS ENS toon in met de toonkeuzeschakelaar.

◎ Selezione di combinazioni di suoni della banca di toni

◆Per selezionare il suono "FLUTE PIANO":
① Selezionare il tono PIANO con il selettore di tono.
② Premere il tasto di banca di tono. L'indicatore sopra il tasto si illumina.
③ Selezionare il tono FLUTE con il selettore di tono.



◆Per poi selezionare il suono "BELLS PIANO":
④ Premere il selettore di tono BELLS.

◆Per selezionare il suono "HARPSI BRASS":
⑤ Premere il tasto di banca di tono per disattivare la funzione. L'indicatore si spegne.
⑥ Selezionare il tono HARPSICHORD.
⑦ Premere di nuovo il tasto di banca di tono. L'indicatore si illumina.
⑧ Selezionare il tono BRASS ENS con il selettore di tono.

NTH-REED	HARP	SYNTH-CELESTA	SYNTH-CLAVI	FANTASY	MIRACLE	BASS
REED	PF HARP	PF CELESTA	PF CLAVI 2	FANTASY PIANO	MIRACLE PIANO	BASS PIANO
RPSI REED	HARPSI HARP	H CELESTA	HARPSI CLAVI 2	FANTASY HARPSI	MIRACLE HARPSI	HARPSI BASS
REED	HARP VIB	VIB CELESTA	VIB CLAVI 2	FANTASY VIB	MIRACLE VIB	BASS VIB
GAN REED	JAZZ ORGAN 4	CELESTA ORGAN	ORGAN CLAVI 2	FANTASY ORGAN	MIRACLE ORGAN	BASS ORGAN
E REED	PIPE HARP	PIPE CELESTA	ROCK ORGAN 2	FANTASY PIPE	MIRACLE PIPE	BASS PIPE
ASS REED	BRASS HARP	SYNTH-SOUND 1	SYNTH-BRASS 4	FANTASY BRASS	MIRACLE BRASS	BASS BRASS
REED	HARP STRINGS	SYNTH-SOUND 2	ST CLAVI 2	FANTASY STRINGS	MIRACLE STRINGS	BASS STRINGS
REED	HARP FLUTE	SYNTH-FLUTE 2	FLUTE CLAVI 2	FANTASY FLUTE	MIRACLE FLUTE	BASS FLUTE
NTH-CHORUS 4	HARP CHORUS	SYNTH-CHORUS 5	SYNTH-SOUND 4	FANTASY CHORUS	MIRACLE CHORUS	BASS CHORUS
REED	HARP GUITAR	SYNTH-CELESTA 2	SYNTH-CLAVI 2	FANTASY GUITAR	MIRACLE GUITAR	BASS GUITAR
LS REED	HARP BELLS	SYNTH-BELLS 2	BELLS CLAVI 2	FANTASY BELLS	MIRACLE BELLS	BASS BELLS
NKY REED	HARP CLAVI	FUNKY CELESTA	CLAVI ENS 2	FANTASY CLAVI	MIRACLE CLAVI	SYNTH-BASS 1
ITAL REED	METALLIC HARP	HARPSICHORD 3	DIGITAL ENS 2	FANTASY 2	MIRACLE 2	METALLIC BASS
NTH-REED 2	SYNTH-HARP	SYNTH-CELESTA 3	SYNTH-CLAVI 3	FANTASY 3	MIRACLE 3	SYNTH-BASS 2
RC REED	PERC HARP	PERC CELESTA	PERC CLAVI 2	PERC FANTASY	PERC MIRACLE	PERC BASS
REED	HARP PIANO	SYNTH-CELESTA 4	SYNTH-CLAVI 4	FANTASY 4	MIRACLE 4	BASS HT PIANO
NTH-REED 3	ELEC PIANO 6	ELEC CELESTA	ELEC CLAVI	FANTASY 5	MIRACLE 5	BASS EL PIANO
RIMBA REED	HARP MARIMBA	SYNTH-CELESTA 5	SYNTH-CLAVI 5	FANTASY MARIMBA	MIRACLE MARIMBA	BASS MARIMBA
NTH-REED 4	ORGAN 5	ORG CELESTA	ORGAN CLAVI 4	FANTASY 6	MIRACLE 6	ORG BASS
LO REED 1	POPS ACCORDION	C ACCORDION	SYNTH-SOUND 5	A FANTASY	A MIRACLE	BASS ACCORDION
LO REED 2	HARP TRUMPET	T CELESTA	TRUMPET CLAVI	FANTASY TRUMPET	MIRACLE TRUMPET	SYNTH-BASS 3
LO REED 3	SYNTH-STRINGS 5	SYNTH-ENS 5	ST CLAVI 4	DIGITAL ENS 3	DIGITAL ENS 4	SYNTH-BASS 4
DE REED	HARP OBOE	OBOE CELESTA	OBOE 5	FANTASY OBOE	MIRACLE OBOE	BASS OBOE
	HARP REED	SOLO REED 4	CLAVI ENS 3	FANTASY REED	MIRACLE REED	BASS REED
RP REED		HARP CELESTA	CLAVI ENS 4	FANTASY HARP	MIRACLE HARP	BASS HARP
LO REED 4	HARP CELESTA		CELESTA CLAVI	FANTASY CELESTA	MIRACLE CELESTA	BASS CELESTA
VI ENS 3	CLAVI ENS 4	CELESTA CLAVI		CLAVI ENS 5	CLAVI ENS 6	BASS CLAVI
TASY REED	FANTASY HARP	FANTASY CELESTA	CLAVI ENS 5		M FANTASY	FANTASY BASS
ACLE REED	MIRACLE HARP	MIRACLE CELESTA	CLAVI ENS 6	M FANTASY		MIRACLE BASS
SS REED	BASS HARP	BASS CELESTA	BASS CLAVI	FANTASY BASS	MIRACLE BASS	

OH0117084A Printed in Japan Imprimé au Japon